

How to Attach Anti-Furl Rings

- Slide top and bottom ring onto pole if using two – position lower anti-furl ring with rotating piece closest to flag and screw closest to end of pole. Spring clips should face each other.
- Use the spring clip to attach grommet of flag or tab inside sleeve. If attaching grommet, pinch the clip to open near the top of the grommet material. Clip will be stiff, but doing at the top is less material to maneuver. Pliers may be necessary. Use the screw to tighten ring snugly against pole. Make sure screw is on outside of pole facing down toward ground.
- Leave a little slack in the flag header between top and bottom rings. If flag is stretched too tight, flag will not unfurl properly. Each flag is individually sewn, and slight adjustments may have to be made. Before inserting the flagpole in the bracket holder, hold the pole horizontally, and rotate the pole to make sure the flag rings spin freely with the flag attached.
- Adjustments may be necessary – you can loosen the tension on bottom flag ring and put the bottom screw back in. Test by slowly sliding the ring down on pole until you hit the spot where ring stops spinning. Back off tension and set the screw tight. *Note: over tightening the ring screw does distort the shape of the ring which could cause flag furling.*

